How to Use the LMH Wired Microphone v22.01.22

1 Standing on the stage, facing the Hall, on your RHS is the PA (Public Address) cupboard which houses the sound mixer. The wired microphone is normally inside the PA cupboard, to one side of the sound mixer.

2 The wired microphone is sometimes attached to the cable.

3 Sometimes you have to find the cable and attach it yourself.

4 Put the mic cable into the mixer unit – input A in column 1 on extreme LHS. This column is labelled “Mic 1” at the top and “1” at the bottom. Turn the “Input Volume Level” on this input to 0 (for the moment).

5 Switch on the power to the sound mixer unit.
(Socket at ground level below PA cupboard.)

6 On the sound mixer check that the “MASTER DO NOT ALTER” control is at 12 o’clock.
Switch on the mixer unit (On/Off push button at bottom RHS of mixer unit).

7 Switch on the mic (On/Off slide on mic).

8 You should now be good to go. Start to speak into the mic, and turn the "Input Volume Level" (under Mic 1) up until you are happy with the sound.

9 Spare Keys for PA cupboard
Sometimes the PA cupboard is locked. There are spare keys in the Key Safe in the Boiler Room.

The Trustees January 2022